

### Product Information MPU-4(B)

# Pt100 Two-wire Input Transmitter MPU-4(B)

#### Application / Specified Usage

The two-wire input transmitter MPU-4 (B) converts the temperature signal of the resistance thermometer into a scaled signal (4...20 mA) proportional to the temperature, whereby the two-wire loop is conducting both the power supply (voltage) and the output signal (current).

The module directly can be mounted into the connecting head of the temperature sensor (e.g. TFP-40).

By mounting the transmitter directly at the point of measurement no additional converter in a cabinet system is necessary, this resulting in the advantages of low installation costs, uncomplicated wiring and high noise immunity.

The transmitter MPU-4(B)G mounted in a stable Polyamide case - especially suits for temperature sensors with wiring but without connecting head.

#### Features

- · Installation into the sensor head (e.g. TFP-40)
- Fully potted module
- Connection directly to the PLC
- · Temperature linear 4...20 mA signal

#### **Options / Accessories**

- · Special measurement ranges
- · 2-, 3- or 4-wire connection
- · Programming adpater MPU-P 9701
- · Transmitter in Polyamide housing, option MPU-4(B)G

Specification transmitter MPU-4(B)		
Temperature ranges	ambient storage	-40+85 °C -55+90 °C
Measuring ranges		standard: -1040 °C, 050 / 100 / 150 / 200 °C special ranges free programmable
Accuracy	input	< ±0,25 °C
Temperature drift	zero, span	< 0,01 %/K
Supply	accuracy	835 V DC 0,01 %/V (reference: 12 V DC)
Output	signal accuracy burden	analog 420 mA < $\pm$ 0,1 % of measurement range < 600 $\Omega$ (at U <sub>B</sub> = 24 V)
Humidity	without condensation	098 %

Authorizations

CE




CONTROLS


# CONTROLS

2


# Electrical connection to digital indicator DPM-GS



#### **Electrical connection to PLC**



#### Option MPU-4(B)G 3-/4-wire connection



#### Advice to EMC

• The device agrees to following standards: EMC directive 2004/118/EC.

### Disposal



EMC directive 2004/118/EC.

# • This instrument is not subject to the WEEE directive 2002/96/EC and the respective national laws.

 Pass the instrument directly on to a specialised recycling company and do not use the municipal collecting points.

# Transport / Storage

- Use suitable transport packaging only to avoid damage of the equipment!
- · No outdoor storage
- Store dry and dust free
- · Not exposed to corrosive media
- Protected against solar radiation
- · Avoiding mechanical shock and vibration
- · Storage temperature -10...+70 °C
- · Relative humidity maximum 95 %

50004 / 2.0 / 2015-02-16 / TB /EU

NEGELE MESSTECHNIK GMBH Raiffeisenweg 7 87743 Egg an der Guenz Phone +49 (0) 83 33 . 92 04 - 0 Fax +49 (0) 83 33 . 92 04 - 49 sales@anderson-negele.com Tech. Support: support@anderson-negele.com Phone +49 (0) 83 33 . 92 04 - 720